

# Fast and Simple Troffer Retrofit Kit Installation

No lamp holder rewiring required

**LEDSTICK**  
COMPANY



Remove lamps and if required by local code or utility rebate program, the ballast. No need to remove the lamp holders.

Connect SY driver to incoming power. The driver attaches to the fixture with magnets.



Plug the jumper from the SY driver into SL lamp #1. Use a provided 10" or 18" jumper to connect SL lamp #1 to SL lamp #2. The SL lamps attach to the fixture with magnets.

Position the SL lamps in the fixture.



Replace the ballast cover.

