

LMIC



DLC NLC 5.0 LISTED – Network Lighting Control

Compatible with all 0-10VDC LED Drivers | Bluetooth Mesh Network

LMIC-R Fixture Controller

Mounts in Ballast Cover or Belly Pan



LMIC-R (J-Box) Fixture Controller

Can be mounted in Ballast Cover or Belly Pan





LMIC-TPIR PIR Motion Sensor & Remote Control Battery Powered Motion Sensor and Remote Control – Allows for Manual Override of Network Program (On/Off and Dim +/-)

LMIC-T Motion Sensor 110-277V AC




LMIC-R Fixture Controller

Installed in Strip Fixture Belly Pan with Power Whip for LMK4xx-DIM



LMIC-R Fixture Controller

Installed in 2x2 Troffer, with SY18W-DIM LED Driver





Specification sheets for each component are available at www.ledstick.net/resources Find LMIC Utility Rebate/Incentives – Click HERE

Distributed by LED Stick Company www.ledstick.net (888) 924-4533